
Disassembly & Material Call Out

ergotron®

Zip12 Charging Wall Cabinet: DM12-1006



Equipment & Accessories Disposal

- 1. Please dispose of all batteries in accordance with local law.
- 2. All Electronics should be recycled through an electronics recycler.
- 3. Remaining plastics and metals can be recycled through a commercial recycler.

See website for more recycling information: www.ergotron.com/en-us/company/environmentally-responsible www.ergotron.com | USA: 1-800-888-8458 | Europe: +31 (0)33-45 45 600 | China: 400-120-3051 | Japan: japansupport@ergotron.com © 2024 Ergotron, Inc. All rights reserved.

There may be components that are under pressure. Proceed with caution while disassembling.