





15 minute Disassembly
Tools Needed:



Disassembly & Material Call Out

StyleView Power Cord
97-910, 97-911, 97-917,
97-918, 97-920, 97-921



Equipment & Accessories Disposal

1. Please dispose of all batteries in accordance with local law.
2. All Electronics should be recycled through an electronics recycler.
3. Remaining plastics and metals can be recycled through a commercial recycler.

See website for more recycling information: www.ergotron.com/en-us/company/environmentally-responsible

www.ergotron.com | USA: 1-800-888-8458 | Europe: +31 (0)33-45 45 600 | China: 400-120-3051 | Japan: japansupport@ergotron.com

© 2024 Ergotron, Inc. All rights reserved.



There may be components that are under pressure. Proceed with caution while disassembling.